



... FS ...  
**FLIGHT**  
C O N T R O L  
[www.fs-flightcontrol.com](http://www.fs-flightcontrol.com)

# FS-FlightControl

## Manual

**Instructor Operator Station**  
for Microsoft Flight Simulator, Prepar3D and X-Plane



**FS-FlightControl · AB-Tools GmbH**

E-mail: [info@fs-flightcontrol.com](mailto:info@fs-flightcontrol.com) · Internet: [www.fs-flightcontrol.com](http://www.fs-flightcontrol.com)

Marsstraße 78, 80335 München, Germany · Phone: +49 89 38898588 · Fax: +49 89 38898589

Bank Account: Grenke Bank AG · IBAN: DE 49 20130400 0060270139 · BIC: GREBDEH1XXX

Register: Amtsgericht München, HRB 202859 · Finance Office: München für Körperschaften · VAT ID DE273587389

# Table of Contents

<b>MOTION</b> .....	1
<b><i>Profile</i></b> .....	1
<b><i>Hardware Status</i></b> .....	1
<b><i>Simulator Status</i></b> .....	1
<b><i>Motion Device Status Pilot</i></b> .....	1
<b><i>Motion Device Status Copilot</i></b> .....	2
<b><i>Motion Device Status General</i></b> .....	2
<b><i>Legend</i></b> .....	2

## MOTION

Control and monitor motion as well as control loading devices by Brunner Elektronik

This way you remote control the software **CLS2Sim** provided by Brunner Elektronik that all everyday tasks can directly be monitored and controlled from within **FS-FlightControl**.

Only for in-depth profile changes you still need to use **CLS2Sim** directly.

### Profile



First the currently active profile is displayed.

Additionally you have the option here to select a different profile and active it.

### Hardware Status



The hardware status shows if **CLS2Sim** is currently connected to the motion and control loading devices.

If that is the case you can use the buttons **Initialize**, **Stop** and in case of current problems also **Fault Reset** to trigger corresponding actions regarding the devices.

### Simulator Status



The simulator status shows if **CLS2Sim** is currently connected to a flight simulator. This also includes the name of the flight simulator.

You can use the button showing **Connect** or **Disconnect** accordingly.

### Motion Device Status Pilot



Here you see the current status of all motion devices related to the pilot position.

## Motion Device Status Copilot



Here you see the current status of all motion devices related to the copilot position.

## Motion Device Status General



Here you see the current status of the remaining motion devices not related to a pilot position.

## Legend



Finally the color legend of the status color is shown here.

**FS-FlightControl Manual:**

<https://www.fs-flightcontrol.com/en/manual/>

**PDF Generated on:**

2026-01-24 04:22

