

Table of Contents

Select Airport 1

Select Airport



Select an airport either by entering the ICAO code directly or by selecting it based on the country and city list. A random airport is possible as well.

For a more detailed explanation see also the identical airport selection in the [airport_selection](#) module.

FS-FlightControl Steam Products Manual:
<https://www.fs-flightcontrol.com/en/steam/manual/>



PDF Generated on:
2026/05/31 01:32