

# Table of Contents

**Select Airport** ..... 1

# Select Airport



Select an airport either by entering the ICAO code directly or by selecting it based on the country and city list. A random airport is possible as well.

For a more detailed explanation see also the identical airport selection in the [Position](#) module.

**FS-FlightControl Steam Products Manual:**  
<https://www.fs-flightcontrol.com/en/steam/manual/>



**PDF Generated on:**  
2026/05/30 22:51