

# Table of Contents

- Motion** ..... 1
- Profile** ..... 1
- Hardware Status** ..... 1
- Simulator Status** ..... 1
- Motion Device Status Pilot** ..... 1
- Motion Device Status Copilot** ..... 2
- Motion Device Status General** ..... 2
- Legend** ..... 2

# Motion

Operate and monitor motion as well as control loading devices by [Brunner Elektronik](#).

This way you remote control the software CLS2Sim provided by Brunner Elektronik that all everyday tasks can directly be monitored and controlled from within FS-FlightControl.

Only for in-depth profile changes you still need to use CLS2Sim directly.

## Profile



First the currently active profile is displayed.

Additionally you have the option here to select a different profile and active it.

## Hardware Status



The hardware status shows if CLS2Sim is currently connected to the motion and control loading devices.

If that is the case you can use the buttons `Initialize`, `Stop` and in case of current problems also `Fault Reset` to trigger corresponding actions regarding the devices.

## Simulator Status



The simulator status shows if CLS2Sim is currently connected to a flight simulator. This also includes the name of the flight simulator.

You can use the button showing `Connect` or `Disconnect` accordingly.

## Motion Device Status Pilot



Here you see the current status of all motion devices related to the pilot position.

## Motion Device Status Copilot



Here you see the current status of all motion devices related to the copilot position.

## Motion Device Status General



Here you see the current status of the remaining motion devices not related to a pilot position.

## Legend



Finally the color legend of the status color is shown here.

**FS-FlightControl Steam Products Manual:**  
<https://www.fs-flightcontrol.com/en/steam/manual/>



**PDF Generated on:**  
2026/05/19 07:26