



FS  
**FLIGHT**  
CONTROL  
[www.fs-flightcontrol.com](http://www.fs-flightcontrol.com)

# FS-FlightControl

## Manual

### **Instructor Operator Station**

for Microsoft Flight Simulator, Prepar3D and X-Plane



**FS-FlightControl · AB-Tools GmbH**

E-mail: [info@fs-flightcontrol.com](mailto:info@fs-flightcontrol.com) · Internet: [www.fs-flightcontrol.com](http://www.fs-flightcontrol.com)

Marsstraße 78, 80335 München, Germany · Phone: +49 89 38898588 · Fax: +49 89 38898589

Bank Account: Grenke Bank AG · IBAN: DE 49 20130400 0060270139 · BIC: GREBDEH1XXX

Register: Amtsgericht München, HRB 202859 · Finance Office: München für Körperschaften · VAT ID DE273587389

# Table of Contents

POSITION

Airport Selection

Directly by ICAO Code

Search by Country and City

Runways or Helipads

Runway/Helipad Information

Approach Training

Helipads

SID and STAR Waypoints

Airworks

Custom Location

From Runway Landing Point

At Coordinate

Gate or Parking

Options

Flight Situation Presets

Create New Flight Situation Preset

1

1

1

1

2

2

3

3

4

5

5

6

6

6

7

7

## POSITION

Move your aircraft on an approach, to a runway takeoff point, on a helipad, a gate or parking position or any other custom geographical location you choose.

## Airport Selection

There are two options to select an airport.

### Directly by ICAO Code

**Airport ICAO:**

Just enter the ICAO code of the airport in the corresponding field and the airport will load immediately.

Alternatively you can also use the button Random to choose a random airport.

### Search by Country and City



If you don't know the ICAO code of the airport, you can also select an airport based on the country and the next big city the airport belongs to: Just first select the country, then the city and finally pick an airport from the list.

## Runways or Helipads

Runways and Helipads

08R (ILS)

26L (ILS)

08L (ILS)

26R (ILS)

Heli

Runway Information - Type of Surface: **Concrete**

Length: **13,097 ft** Altitude: **1,487 ft** Heading: **81°** ILS Frequency: **109.30 MHz**


Approach Training

SID, STAR Waypoints


Airwork

Custom Location


Approach Training




Downwind Left  
4 NM, Back 1 NM




Take Off




Downwind Right  
4 NM, Back 1 NM




Vectors Left  
2 NM, Final 6 NM




3 NM Final




Vectors Right  
2 NM, Final 6 NM



Base Left  
4 NM, Final 6 NM



8 NM Final



Base Right  
4 NM, Final 6 NM

Show Airport on Map

Show Airport METAR

Now you can choose on which runway or helipad you want your aircraft to be place.


## Runway/Helipad Information

Runway Information - Type of Surface: **Concrete**

Length: **13,097 ft** Altitude: **1,487 ft** Heading: **81°** ILS Frequency: **109.30 MHz**

After selecting a runway some additional information about this runway is displayed. For helipads this information is not displayed before you choose a specific helipad in the next step.

## Approach Training

 Note: This option is only available if you chose a runway.

FS-FlightControl Manual: <https://www.fs-flightcontrol.com/en/manual/>




To start an approach training just click on one of the button to place your aircraft it the corresponding position.

If the runway is ILS enabled the correct altitude above ground will be calculated using the runway-specific glideslope degree. Otherwise the default of 3° will be used.

All parameters like distance to landing point for the two final positions, distance for the base positions or altitude above ground for the downwind positions can be configured in the **Settings** module.

## Helipads

 Note: This option is only available if you chose Heli.



Click on one of the helipad buttons to place the aircraft on a helipad.

## SID and STAR Waypoints

SID and STAR Waypoints

Procedure Type:

☒ Standard Instrument Departure (SID)
   
☐ Standard Terminal Arrival Route (STAR)
   
☐ Approach Transition (APPTR)
   
☐ Final Approach (FINAL)

Procedure Ident:

ALG2E.08R.ALG
   
 ANKE9E.08R.ANKER
   
 BIBA2E.08R.BIBAG
   
 EVIV3E.08R.EVIVA
   
 GIVM5E.08R.GIVMI
   
 INPU2E.08R.INPUD
   
 KIRD2E.08R.KIRDI
   
 MERS1P.08R.MERSI

You can place the aircraft directly on a waypoint of a Standard Instrument Departure (SID) or Standard Terminal Arrival Route (STAR).

First select which the desired procedure type and then the procedure ident. Finally you can select one waypoint of the procedure you have chosen.

SID and STAR Waypoints

Procedure Type:


☒ Standard Instrument Departure (SID)
   
☐ Standard Terminal Arrival Route (STAR)
   
☐ Approach Transition (APPTR)
   
☐ Final Approach (FINAL)

Procedure Ident: **BIBA2E.08R.BIBAG**

Waypoint Ident: **RATGI**

**Move Aircraft to Waypoint**

Now click on the button **Move Aircraft to Waypoint** to change the aircraft position accordingly.

 **Note:** The heading of the aircraft will be automatically set to match the direction to the next waypoint in the procedure.

## Airworks



Choose one of four pre-defined flight levels to start your airworks.

Of course, also these altitudes can be easily changed in the **Settings** module.

## Custom Location

Custom Location

Altitude:

5000

ft

Heading:

220

°

☒ From Runway Landing Point

Angle:

60

°

Distance:

3

NM

☐ At Coordinates

Latitude:

48

N

21

'

13.62

"

Longitude:

11

E

47

'

9.91

"

Set Custom Location

If you want your aircraft to be placed at a completely custom location, this is the right section for you.

First enter the desired altitude (above MSL) and heading of the aircraft. Then you can choose from two options to define the position.

### From Runway Landing Point

From Runway Landing Point

Angle:

60

°

Distance:

30

NM

Using this option the aircraft will be move a definable distance away from the runway landing point with in the entered direction.

### At Coordinate




At Coordinates					
Latitude:	48	N	21	13.62	"
Longitude:	11	E	47	9.91	"

Or you can just enter the exact geographic coordinates manually where you want the aircraft to be place.

The fields are pre-filled with the coordinates of the currently loaded airport.

## Gate or Parking



Gate or Parking	
Type:	
	Fuel
	Gate Heavy
	Gate Medium
	Gate Small
	Ramp Cargo
	Ramp General Aviation Large
	Ramp General Aviation Medium
	Ramp General Aviation Small

You can also place your aircraft on a gate or parking position.

Therefore first select the type and then a specific gate or parking.



Gate or Parking	
Type:	Gate Medium
Gate or Parking:	Gate 102
<b>Move Aircraft to Gate or Parking</b>	

And then click on the button Move Aircraft to Gate or Parking to finally place the aircraft.

## Options



Options


IAS:  kt ☒ Set Gear: ☒ Down ☐ Override Altitude: Set: ☒ HDG ☒ CRS

Pitch:  ° ☒ Set Flaps:  °  ft MSL ☒ ILS Frequency

Here you can find several options like speed and gear/flaps status that are used when placing the aircraft.

All options are saved upon change and can even be defined on a per-aircraft level when aircraft profiles are enabled in the **Settings** module.

Use the button Show Airport on Map to switch to the **Map** module and center the map on the current airport.

 Note: When aircraft is placed on ground gear is always extended and ILS frequency can only be set if the runway is ILS enabled.

## Flight Situation Presets


Flight Situation Presets

Approach EDDM 5 NM	Approach New York	SID KLAX HOLTZ9
STAR KJFK PARCH1	Take Off LA 25R	Take Off Tegel 26L
Back	Add	Next
Reset Current Flight Situation		

Here you can save the current situation including aircraft position, altitude, speed, heading, pitch and bank angle.

If there are more than 6 presets, you can page through them using the buttons Back and Next.

## Create New Flight Situation Preset



After clicking on the button Add to create a new situation preset or click on an existent one to load it.

**FS-FlightControl Manual:**

<https://www.fs-flightcontrol.com/en/manual/>



**PDF Generated on:**

2025-09-15 23:07