



FS
FLIGHT
CONTROL
www.fs-flightcontrol.com

FS-FlightControl

Manual

Instructor Operator Station

for Microsoft Flight Simulator, Prepar3D and X-Plane



FS-FlightControl · AB-Tools GmbH

E-mail: info@fs-flightcontrol.com · Internet: www.fs-flightcontrol.com

Marsstraße 78, 80335 München, Germany · Phone: +49 89 38898588 · Fax: +49 89 38898589

Bank Account: Grenke Bank AG · IBAN: DE 49 20130400 0060270139 · BIC: GREBDEH1XXX

Register: Amtsgericht München, HRB 202859 · Finance Office: München für Körperschaften · VAT ID DE273587389

Table of Contents

MOTION

Motion Platform

Profile

Platform Status

Motor Status

Legend

Control Loading

Profile

Hardware Status

Simulator Status

Device Status Pilot

Device Status Copilot

Device Status General

Legend

1

1

1

2

2

2

3

3

4

4

4

4

MOTION

Operate and monitor motion as well as control loading devices by **Brunner Elektronik**.

This way you remote control the software CLS2Sim provided by Brunner Elektronik that all everyday tasks can directly be monitored and controlled from within FS-FlightControl.

Only for in-depth profile changes you still need to use CLS2Sim directly.

Motion Platform

Motion Platform

Profile

Current Profile: **Default Profile**

Change Profile:

Platform Status

☒ Operational ☒ Position: Simulator ☒ Weight: 476 kg

Motor Status

<input checked="" type="checkbox"/> Operational	<input checked="" type="checkbox"/> Operational	<input checked="" type="checkbox"/> Operational	<input checked="" type="checkbox"/> Operational	<input checked="" type="checkbox"/> Operational	<input checked="" type="checkbox"/> Operational
98°F, 538 ft lbf	113°F, 674 ft lbf	138°F, 688 ft lbf	136°F, 462 ft lbf	113°F, 460 ft lbf	131°F, 623 ft lbf

Legend

☐ Disconnected, Stopped ☐ Initializing, Measuring ☒ Connected, Operational ☐ Fault, Details in Tooltip

The first section is about your motion platform.

Profile

Profile

Current Profile: **Default Profile**

Change Profile:

First the currently active profile is displayed.

Additionally you have the option here to select a different profile and active it.

Platform Status

Platform Status

Initialize

Simulate

Park

Stop

Operational

Position: Simulator

Weight: 476 kg

The platform status shows if it is currently operational as well as what the current position and weight of the platform is.

You can also use the buttons `Initialize`, `Simulate`, `Park` and `Stop` to trigger corresponding actions regarding the devices.

Motor Status

Motor Status

Operational
99°F, 538 ft lbf

Operational
113°F, 674 ft lbf

Operational
138°F, 688 ft lbf

Operational
136°F, 462 ft lbf

Operational
113°F, 460 ft lbf

Operational
131°F, 623 ft lbf

The motor status shows if each of the motors is currently operational as well as what the current temperature and force is.

Legend

Legend

Disconnected, Stopped


Initializing, Measuring

Connected, Operational

Fault, Details in Tooltip


Finally the color legend of the status colors is shown here.

Control Loading



The second section is about your control loading devices.

Profile



First the currently active profile is displayed.

Additionally you have the option here to select a different profile and active it.

Hardware Status



The hardware status shows if CLS2Sim is currently connected to the motion and control loading devices.

If that is the case you can use the buttons Initialize, Stop and in case of current problems also

Fault Reset to trigger corresponding actions regarding the devices.


Simulator Status



The simulator status shows if CLS2Sim is currently connected to a flight simulator. This also includes the name of the flight simulator.


You can use the button showing Connect or Disconnect accordingly.

Device Status Pilot




Here you see the current status of all motion devices related to the pilot position.

Device Status Copilot



Here you see the current status of all motion devices related to the copilot position.

Device Status General



Here you see the current status of the remaining motion devices not related to a pilot position.

Legend



Finally the color legend of the status colors is shown here.

FS-FlightControl Manual:
<https://www.fs-flightcontrol.com/en/manual/>



PDF Generated on:
2025-07-31 14:29